10X10FT-BOOTH-C

STEPS

(1) Hardware

x4

(2) Printed Graphic Fabric Banner (Optional)

STEP 01 Connect to make long poles according to labelings.

x4

Press Knobs to Lock
Poles with Bungees

x4

STEP 02 Connect long poles with corner poles according to labelings.

a   a

a   a

a Press Knobs to
Lock Poles

STEP 03 Slide fabric banner on frame from top and zip up at bottom.

Same Steps for Other Display Stands

STEPS

(1) Hardware

(2) Printed Graphic Fabric Banner (Optional)

STEP 01

Connect poles according to labelings.

ⓑ ⓑ ⓑ

ⓑ Press Knobs to Lock Poles

STEP 02

Slide fabric banner on frame from left and zip up at right.

STEPS

(1) Base
x2   x1

(3) 180° C-Shaped Clip
x4

(4) LED Light & Clip
x1
x1

STEP 01

Insert display stands onto feet by pressing their knobs.

C   C   C

STEP 02

Interconnect display stands with C-shaped clips.

d   d
d
d
d

STEPS

STEP 03

Screw light clips at top of display stands, slide lights onto them and adjust their direction.

10X10FT-BOOTH-C

iPad Brochure Stand

★ One Tool (Hex Wrench)

STEPS

(1) Snap Tubes

**(2)** Printed fabric banner

**(3)** Brochure rack x 2 / Screws x 4
Tablet PC holder x1

STEP 01

To Connect the tubes according to the labellings

Bungee pole connects
by push button

STEP 02

To connect 2 long side tubes by the corner pieces

a

a PRESS

STEPS

STEP 03

To install the cross bar according to labellings

STEP 04

To wrap the fabric from top to the middle of frame, then put the iPad in the holder and adjust the holder to right size and lock it by Allen Key Afterwards, install the set to the display stand.

STEPS

STEP 05

To pull the fabric banner to bottom and zip up.

STEP 06

To Install 2 racks by screws in position

STEPS

(1) Durable Plastic Hard Case, Aluminum Support Poles

(2) Printed Graphic Fabric Banner

STEP 01

Put hard case's top into fabric banner.

Case's Top

Fabric Banner

STEP 02

Insert support poles into hard case's top & bottom.

Case's Bottom

STEPS

STEP 04

Wrap fabric banner from bottom to top & twist it to be smooth, lay hard case's intermediate panel on podium's top.

★ One Tool (Hex Wrench)

STEPS

(1) Straight Support Poles

x3
x3

x3
x3

x3

**(2)** Top MDF Board, Bottom MDF Board, Acrylic Boards

(3) Printed Graphic Fabric Banner

STEP 01

Connect straight support poles by pressing knobs to lock.

PRESS

STEP 02

Insert fabric banner into bottom MDF board's slot and turn it over.

BOTTOM

PRESS

STEPS

STEP 03

Screw straight support poles in bottom MDF board's threaded holes and place top MDF board on them.


STEP 04

Pull fabric banner from bottom to top and insert into top MDF board's slot.

PRESS

STEPS

STEP 05

Screw straight support poles with threaded holes filled onto nuts and place acrylic boards on them layer by layer.

STEPS

DT-S-03

DT-S-01

DT-S-02